

## 三 极 管 系 列

品 名	极性	管脚	功 能	参 数
MPSA42	NPN	21E	电话视频放大	300V0.5A0.625W
MPSA92	PNP	21E	电话视频放大	300V0.5A0.625W
MPS2222A	NPN	21	高频放大	75V0.6A0.625W300MHZ
9011	NPN	EBC	高频放大	50V30mA0.4W150MHz
9012	PNP	贴片	低频放大	50V0.5A0.625W
9013	NPN	EBC	低频放大	50V0.5A0.625W
9013	NPN	贴片	低频放大	50V0.5A0.625W
9014	NPN	EBC	低噪放大	50V0.1A0.4W150MHZ
9015	PNP	EBC	低噪放大	50V0.1A0.4W150MHZ
9018	NPN	EBC	高频放大	30V50MA0.4W1GHZ
8050	NPN	EBC	高频放大	40V1.5A1W100MHZ
8550	PNP	EBC	高频放大	40V1.5A1W100MHZ
2N2222	NPN	4A	高频放大	60V0.8A0.5W25/200NS $\beta$ =45
2N2222A	NPN	小铁	高频放大	75V0.6A0.625W300MHZ
2N2369	NPN	4A	开关	40V0.5A0.3W800MHZ
2N2907	NPN	4A	通用	60V0.6A0.4W26/70NS $\beta$ =200
2N3055	NPN	12	功率放大	100V15A115W
2N3440	NPN	6	视放 开关	450V1A1W15MHZ
2N3773	NPN	12	音频功放开关	160V16A150W COP 2N6609
2N3904	NPN	21E	通用	60V0.2A $\beta$ =100-400
2N3906	PNP	21E	通用	40V0.2A $\beta$ =100-400
2N5401	PNP	21E	视频放大	160V0.6A0.625W100MHZ
2N5551	NPN	21E	视频放大	160V0.6A0.625W100MHZ
2N5685	NPN	12	音频功放开关	60V50A300W
2N6277	NPN	12	功放 开关	180V50A250W
2N6609	PNP	12	音频功放开关	160V15A150W COP 2N3773

2N6678	NPN	12	音频功放开关	650V15A175W15MHZ
2N6718	NPN	小铁	音频功放开关	100V2A2W50MHZ
3DA87A	NPN	6	视频放大	100V0.1A1W
3DG6A	NPN	6	通用	15V20mA0.1W100MHZ
3DG6B	NPN	6	通用	20V20mA0.1W150MHZ
3DG6C	NPN	6	通用	20V20mA0.1W250MHZ
3DG6D	NPN	6	通用	30V20mA0.1W150MHZ
3DG12C	NPN	7	通用	45V0.3A0.7W200MHZ
3DK2B	NPN	7	开关	30V30mA0.2W
3DK4B	NPN	7	开关	40V0.8A0.7W
3DK7C	NPN	7	开关	25V50mA0.3W
3DD15D	NPN	12	电源开关	300V5A50W
3DD102C	NPN	12	电源开关	300V5A50W
3522V			5.2V稳压管	录像机用
A634	PNP	28E	音频功放开关	40V2A10W
A708	PNP	6	NF/S	80V0.7A0.8W
A715C	PNP	29	音频功放开关	35V2.5A10W160MHZ
A733	PNP	21	通用	50V0.1A180MHZ
A741	PNP	4	S	20V0.1A <70/120nS
A781	PNP	39B	开关	20V0.2A <80/160NS
A928	PNP	ECB	通用	20V1A0.25W
A933	PNP	21	Uni	50V0.1A140MHZ
A940	PNP	28	音频功放开关	150V1.5A25W4MHZ /C2073
A950	PNP	21	通用	30V0.8A0.6W
A966	PNP	21	音频激励输出	30V1.5A0.9W COP:C2236
A968	PNP	28	音频功放开关	160V1.5A25W100MHZ /C2238
A1009	PNP	BCE	功放开关	350V2A15W
A1012	PNP	28	音频功率放	60V5A25W
A1013	PNP	21	视频放大	160V1A0.9W
A1015	PNP	21	通用	60V0.15A0.4W8MHZ

A1020	PNP	21	音频 开关	50V2A0.9W
A1123	PNP	21	低噪放大	150V0.05A0.75W
A1162	PNP	21d	通用 贴片	50V0.15A0.15W
A1216	PNP	BCE	功放 开关	180V17A200W20MHZ /2922
A1220	PNP	29	音频功放开关	120V1.5A20W150MHZ/C2690
A1265	PNP	BCE	功放 开关	140V10A100W30MHZ /C3182
A1295	PNP	BCE	功放 开关	230V17A200W30MHZ /C3264
A1301	PNP	BCE	功放 开关	160V10A100W30MHZ /C3280
A1302	PNP	BCE	功放 开关	200V15A150W30MHZ /C3281
A1358 ?	PNP		高频	120V1A10W120MHZ
A1444	PNP	BCE	高速电源开关	100V15A30W80MHZ
A1494	PNP	BCE	功放 开关	200V17A200W20MHZ /C3858
A1516	PNP	BCE	功放 开关	180V12A130W25MHZ
A1668	PNP	28B	电源 开关	200V2A25W20MHZ
A1785	PNP	BCE	驱动	400V1A1W/120V1A0.9W140MH
A1941	PNP	BCE	功放开关	140V10A100WCOP:5198
A1943	PNP	BCE	功放 开关	230V15A150W /C5200 原
A1988	PNP	30	功放 开关	
B449	PNP	12	功放开关	50V3.5A22.5W 锗管
B631K	PNP	29	音频功放开关	120V1A8W130MHZ /D600K
B647	PNP	21	通用	120V1A0.9W140MHZ /D667
B649	PNP	29	视放	180V1.5A1W /D669
B669	PNP	28	达林顿 功放	70V4A40W
B673	PNP	28	达林顿 功放	100V7A40W
B675	PNP	28	达林顿 功放	60V7A40W
B688	PNP	BCE	音频功放开关	120V8A80W /D718
B734	PNP	39B	通用	60V1A1W /D774
B744	PNP	21	通用	30V0.1A0.25W
B772	PNP	29	音频功放开关	40V3A10W
B774	PNP	21	通用	30V0.1A0.25W

B817	PNP	30	功放开关	160V12A100W /D1047
B834	PNP	28	功放开关	60V3A30W
B937A	PNP		功放开关	60V2A35 DRAL
B1020	PNP	28	功放开关	达林顿100V7A40W $\beta$ =6000
B1079	PNP	30	达林顿功放	100V20A100W $\beta$ =5000/D1559
B1185	PNP	28B	功放开关	60V3A25W 70MHZ /D1762
B1238	PNP	ECB	功放开关	80V0.7A1W 100MHZ
B1240	PNP	39B	功放开关	40V2A1W100HZ
B1243	PNP	39B	功放开关	40V3A1W70HZ
B1316	PNP	54B	驱动功放	达林顿100V2A10W $\beta$ =15000
B1317	PNP	BCE	音频功放	180V15A150W COP:D1975
B1335	PNP	28	音频功放低噪	80V4A30W 12MHZ
B1375	PNP	BCE	音频功放	60V3A2W9MHZ
B1400	PNP	28B	达林顿功放	120V6A25W $\beta$ =1000-20000
B1429	PNP	BCE	功放开关	180V15A150W
B1494	PNP	BCE	达林顿功放	120V25A120W $\beta$ =2000-20000
C106	NPN	EBC	音频功放开关	60V1.5A15W
C380	NPN	21	高频放大	35V0.03A250MHZ
C458	NPN	21	通用	30V0.1A230MHz
C536	NPN	21	通用	40V0.1A180MHZ
C752	NPN	21	通用	30V0.1A300MHz
C815	NPN	21	通用	60V0.2A0.25W
C828	NPN	21	通用	45V0.05A0.25W
C900	NPN	21	低噪放大	30V0.03A100MHZ
C943	NPN	4A	通用	60V0.2A200MHZ
C945	NPN	21	通用	50V0.1A0.5W250MHZ
C1008	NPN	6	通用	80V0.7A0.8W50MHZ
C1162	NPN	29	音频功放开关	35V1.5A10W
C1213	NPN	39B	监视器专用	35V0.5A0.4W
C1222	NPN	21	低噪放大	60V0.1A100MHZ

C1494 ?	NPN	40A	发射	36V6A PQ=40W/175MHZ
C1507	NPN	28	视放	300V0.2A15W
C1674	NPN	21	HF/ZF	30V0.02A600MHZ
C1815	NPN	21	通用	60V0.15A0.4W8MHZ
C1855	NPN	21f	HF/ZF	20V0.02A550MHZ
C1875	NPN	12	彩行	1500V3.5A50W
C1906	NPN	21	高频放大	30V0.05A1000MHZ
C1942	NPN	12	彩行	1500V3A50W
C1959	NPN	21	通用	30V0.4A0.5W300MHZ
C1970	NPN	28	手机发射	40V0.6A PQ=1.3W/175MHZ
C1971	NPN	28A	手机发射	35V2.0A PQ=7.0W/175MHZ
C1972	NPN	28A	手机发射	35V3.5A PQ=15W/175MHZ
C2012	NPN	21	HF	30V0.03A200MHZ
C2027	NPN	12	行管	1500V5A50W
C2036				
C2068	NPN	28E	视频放大	300V0.05A1.5W80MHZ
C2073	NPN	28	功率放大	150V1.5A25W4MHZ /A940
C2078	NPN	28	音频功放开关	80V3A10W150MHZ
C2120	NPN	21	通用	30V0.8A0.6W
C2228	NPN	21	视频放大	160V0.05A0.75W
C2230	NPN	21	视频放大	200V0.1A0.8W
C2233	NPN	28	音频功放开关	200V4A40W
C2236	NPN	21	通用	30V1.5A0.9W /A966
C2238	NPN	28	音频功放开关	160V1.5A25W100MHZ /A968
C2320	NPN	21	通用	50V0.2A0.3W200MHZ
C2335	NPN	28	视频 功放	500V7A40W
C2373	NPN	28	功放	200V7.5A40W
C2383	NPN	21	视频 开关	160V1A0.9W /A1015
C2443	NPN	大铁	功放开关	600V50A400W
C2481	NPN	29	音频功放开关	150V1.5A20W

C2482	NPN	21	视频放大	300V0.1A0.9W
C2500	NPN	21	通用	30V2A0.9W150MHZ
C2594	NPN	29	音频功放开关	40V5A10W
C2611	NPN	29	视频放大	300V0.1A1.25W
C2625	NPN	30	音频功放开关	450V10A80W
C2682	NPN	29	NF/Vid	180V0.1A8W
C2688	NPN	29	视放管	300V0.2A10W80MHZ
C2690	NPN	29	音频功放开关	120V1.2A20W150MHZ/A1220P
C2751	NPN	BCE	电源开关	500V15A120W $\beta=40$
C2837	NPN	30	音频功放开关	150V10A100W
C2898	NPN	28	音频功放开关	500V8A50W
C2922	NPN	43	音频功放开关	180V17A200W50MHZ /A1216
C3026	NPN	12	开关管	1700V5A50W $\beta=20$
C3030	NPN	BCE	开关管	达林顿900V7A80W $\beta=15$
C3039	NPN	28	电源开关	500V7A50W $\beta=40$
C3058	NPN	12	开关管	600V30A200W $\beta=15$
C3148	NPN	28	电源开关	900V3A40W $\beta=15$
C3150	NPN	28	电源开关	900V3A50W $\beta=15$
C3153	NPN	30	电源开关	900V6A100W $\beta=15$
C3182	NPN	30	功放开关	140V10A100W $\beta=95/A1265$
C3198	NPN	21	高频放大	60V0.15A0.4W130MHZ
C3262	NPN	BCE	达林顿功放	800V10A100W
C3264	NPN	BCE	PA功放开关	230V17A200W $\beta=170/A1295$
C3280	NPN	30	音频功放开关	160V12A120W $\beta=100$
C3281	NPN	30	音频功放开关	200V15A150W30MHZ $\beta=100$
C3300	NPN	30	音频功放开关	100V15A100W $\beta=600$
C3310	NPN	28C	电源开关	500V5A40W $\beta= 20$
C3320	NPN	28C	电源开关	500V15A80W $\beta= 15$
C3355	NPN	21F	高频放大	20V0.1A6500MHZ

C3358	NPN	40B	高频放大	20V0.1A7000MHZ
C3457	NPN	BCE	电源开关	1100V3A50W $\beta=12$
C3460	NPN	BCE	电源开关	1100V6A100W $\beta=12$
C3466	NPN	BCE	电源开关	1200V8A120W $\beta=10$
C3505	NPN	28B	电源开关	900V6A80W $\beta=20$
C3527	NPN	BCE	电源开关	500V15A100W $\beta=13$
C3528	NPN	BCE	电源开关	500V20A150W $\beta=13$
C3595	NPN	29	射频	30V0.5A1.2W $\beta=90$
C3679	NPN	BCE	电源开关	900V5A100W6MHZ
C3680	NPN	BCE	电源开关	900V7A120W6MHZ
C3688	NPN	BCE	彩行	1500V10A150W
C3720	NPN	BCE	彩行	1200V10A200W
C3783	NPN	BCE	高压高速开关	900V5A100W 黄河21"
C3795	NPN	BCE	高压高速开关	900V5A2W8MHz
C3807	NPN	BCE	低噪放大	30V2A1.2W260MHZ
C3858	NPN	BCE	功放开关	200V17A200W20MHZ /A1494
C3866	NPN	BCE	高压高速开关	900V3A40W
C3873	NPN	BCE	高压高速开关	500V12A75W30MHZ
C3886	NPN	BCE	开关,行管	1400V8A50W8MHZ
C3893	NPN	28B	行管	1400V8A50W8MHZ
C3907	NPN	28B	功放开关	180V12A130W30MHZ
C3953	NPN	29	视放	120V0.2A1.3W 4000MHZ
C3987	NPN	28	达林顿	50V3A20W $\beta=1000$
C3995	NPN	BCE	行管	1500V12A180W 34寸
C3997	NPN	BCE	行管	1500V15A250W
C3998	NPN	BCE	行管	1500V25A250W
C4024	NPN	BCE	功放开关	100V10A35W 24MHZ
C4038	NPN	BCE	门电路	50V0.1A0.3W180MHZ
C4059	NPN	BCE	高速开关	600V15A130W 0.5/2.2US
C4106	NPN	BCE	电源开关	500V7A50W20MHZ?

C4111	NPN	BCE	开关 行管	1500V10A150W
C4119	NPN	BCE	微波炉 开关	1500V15A250W
C4231	NPN	50C	音频功放	800V2A30W
C4237	NPN	BCE	高压高速开关	1000V8A120W30MHZ
C4242	NPN	BCE	高压高速开关	450V7A40W
C4288	NPN	BCE	行管	1400V12A200W8MHZ
C4297	NPN	BCE	电源开关	500V12A75W10MHZ
C4429	NPN	BCE	电源开关	1100V8A60W
C4517	NPN	BCE	音频功放	550V3A30W6MHZ
C4532	NPN	BCE		
C4582	NPN	28b	电源开关	600V15A75W20MHZ
ON4673	NPN	BCE		
ON4873	NPN	BCE		
C4706	NPN	BCE	电源开关	900V14A130W6MHz
C4742	NPN	46	彩行	1500V6A50W(带阻尼)
C4745	NPN	46	彩行	1500V6A50W
C4747	NPN	46	彩行	1500V10A50W
C4769	NPN	BCE	微机行管	1500V7A60W(带阻尼)
C4913	NPN	BCE	大屏视放管	2000V0.2A35W
C4924	NPN	BCE	音频功放	800V10A70W
C4927	NPN	BCE	行管	1500V8A50W
C4927	NPN	BCE	SONY29"行管	1500V8A50W 原装
C4941	NPN	BCE	行管	1500V6A65W 500/380NS
C4953	NPN	BCE		500V2A25W
C5020	NPN	BCE	彩行	1000V7A100W
C5068	NPN	BCE	彩行	1500V10A50W
C5086	NPN	BCE	彩行	1500V10A50W
C5088	NPN	BCE	彩行	1500V10A50W
C5129	NPN	BCE	彩显行管	1500V8A50W(带阻)
C5132	NPN	BCE	彩行	1500V16A50W



C5144	NPN	BCE	大屏彩行	1700V20A200W
C5148	NPN	BCE		
C5149	NPN	BCE	高速高频行管	1500V8A50W(带阻)
C5198	NPN	BCE	功放开关	140V10A100W
C5200	NPN	BCE	功放开关	230V15A150W /A1943 原
C5207	NPN	BCE	彩行	1500V10A50W 原
C5243	NPN	BCE	彩行	1700V15A200W 原
C5244	NPN	BCE	彩行	1700V15A200W
C5249	NPN	BCE		
C5250	NPN	BCE	开关	1000V7A100W 原
C5251	NPN	BCE	彩行	1500V12A50W 原
C5252	NPN	BCE	彩行	1500V15A100W 原
C5294	NPN	BCE		
C5296	NPN	BCE	开关管	25"--34"大屏彩显电源管
C5297	NPN	BCE	开关管	25"--34"大屏彩显电源管
C5331	NPN	BCE	大屏彩显行管	1500V15A180W
C5423	NPN	BCE		
D40C	NPN	ECB	对讲机用	40V0.5A40W75MHZ(达林顿)
D325	NPN	BCE	功放开关	50V3A25W
D385	NPN	11	达林顿功放	100V7A30W
D400	NPN	21	通用	25V1A0.75W
D401	NPN	28	音频功放开关	200V2A20W
D415	NPN	29	音频功放开关	120V0.8A5W
D438	NPN	21	通用	500V1A0.75W100MHz
D547	NPN	大铁	功放开关	600V50A400W
D560	NPN	BCE	达林顿功放	150V5A30W
D600K	NPN	29	音频功放开关	120V1A8W130MHZ/B631K
D637	NPN	39E	通用	60V0.1A150MHZ ****
D667	NPN	21	视频放大	120V1A0.9W140MHZ/B647
D669	NPN	29	视频放大	180V1.5A1W140MHZ/D669

D718	NPN	30	音频功放开关	120V8A80W /B668
D774	NPN	39B	通用	100V1A1W /B734
D789	NPN	21	音频输出	100V1A0.9W
D820	NPN	12	彩行	1500V5A50W
D870	NPN	12	彩行	1500V5A50W RRRR
D880	NPN	28	音频功放开关	60V3A10W
D882	NPN	29	音频功放开关	40V3A30W
D884	NPN	28	音频功放开关	330V7A40W
D898	NPN	12	彩行	1500V3A50W
D951	NPN	12	彩行	1500V3A65W
D965	NPN	21	音频	40V5A0.75W
D966	NPN	21	音频	40V5A1W
D985	NPN	29	功放	150V1.5A10W
D986	NPN	29	功放	150V1.5A10W
D1025	NPN	28	达林顿功放	200V8A50W
D1037	NPN	BCE	音频功放开关	150V30A180W
D1047	NPN	30	音频功放开关	160V12A100W /B817
D1071	NPN	28	功放	300V6A40W DRA-L
D1163A	NPN	28	行偏转用	350V7A40W60MHz
D1175	NPN	12	行偏转用	1500V5A100W $\beta=15$ 原
D1273	NPN	28	音频功放	80V3A40W50MHZ $\beta=1500$
D1302	NPN	21	音频	25V0.5A0.5W200MHZ
D1397	NPN	BCE	开关	1500V3.5A50W3MHz
D1398	NPN	BCE	开关	1500V5A50W3MHz
D1403	NPN	28B	彩行	1500V6A120W
D1403	NPN	28B	彩行	1500V6A120W 原
D1415	NPN	28B	功放电源开关	100V7A40W $\beta=6000$ 达林顿
D1416	NPN	28B	功放电源开关	80V7A40W $\beta=6000$ (达林顿)
D1426	NPN	28B	彩行	1500V3.5A80W $\beta=12$ RRRRR
D1427	NPN	28B	彩行	1500V5A80W $\beta=12$ RRRRR

D1428	NPN	28B	彩行	1500V6A80W $\beta=12$ RRRR
D1431	NPN	28B	彩行	1500V5A80W $\beta=20$
D1433	NPN	28B	彩行	1500V7A80W $\beta=20$
D1439	NPN	BCE	彩行	1500V3A80W $\beta=8$
D1541	NPN	28B	彩行	1500V3A80W $\beta=20$
D1545	NPN	28B	彩行	1500V5A50W $\beta=20$
D1547	NPN	BCE	彩行	1500V7A80W $\beta=20$
D1554	NPN	BCE	彩行	1500V3.5A80W $\beta=12$
D1555	NPN	BCE	彩行	1500V5A80W $\beta=12$
D1556	NPN	BCE	彩行	1500V6A80W $\beta=12$
D1559	NPN	BCE	达林顿功放	100V20A100W $\beta=5000$ /B1079
D1590	NPN	28	达林顿功放	150V8A25W $\beta=15000$
D1632	NPN	28B	彩行	1500V4A70W
D1640	NPN	29	达林顿功放	120V2A1.2W $\beta=4000-40000$
D1651	NPN	SP	彩行	1500V5A60W3MHZ
D1710	NPN	BCE	彩行	1500V5A50W
D1718	NPN	28C	音频功放	180V15A3.5W20MHZ
D1762	NPN	BCE	音频功放开关	60V3A25W90MHZ /B1185
D1843	NPN	BCE	低噪 放大	50V1A1W
D1849	NPN	50A	彩行	1500V7A120W
D1850	NPN	50A	彩行	1500V7A120W
D1859	NPN	50A	音频	80V0.7A1W120MHZ
D1863	NPN	50A	音频	120V1A1W100MHZ
D1877	NPN	30	彩行	1500V4A50W(带阻尼)
D1879	NPN	30	彩行	1500V6A60W(带阻尼)
D1887	NPN	30	彩行	1500V10A70W
D1930	NPN	21	达林顿	达林顿100V2A1.2W $\beta=1000$
D1975	NPN	53A	音频功放	180V15A150W COP:B1317
D1978	NPN	21	达林顿	120V1.5A0.9W $\beta=30000$

D1980	NPN	61B	达林顿	100V2A10W $\beta$ =1000-10000
D1981	NPN	ECB	达林顿	100V2A1W
D1993	NPN	45B	音频低噪	55V0.1A0.4W
D1994A	NPN	ECB	音频驱动	60V1A1W
D1997	NPN	45B	激励管	40V3A1.5W100MHZ
D2008	NPN	ECB	音频功放	80V1A1.2W
D2012	NPN	BCE	音频功放	60V3A2W3MHZ
D2136	NPN	ECB	功放	80V1A1.2W
D2155	NPN	53A	音频功放	180V15A150W
D2256	NPN	46	达林顿功放	120V25A125W $\beta$ =2000-20000
D2334	NPN	28B	彩行	1500V5A80W
D2335	NPN	BCE	彩行	1500V7A100W
D2349	NPN	BCE	大屏彩显行管	
D2374	NPN	BCE		
D2375	NPN	BCE		
D2388	NPN	EBC	达林顿	90V3A1.2W
D2445	NPN	BCE	彩行	1500V12.5A120W
D2498	NPN	BCE	彩行	1500V6A50W
D2588	NPN	BCE	点火器用	
DK55	NPN	BEC	开关	400V4A60W
BC307	PNP	21a	通用	50V0.2A0.3W
BC327	PNP	CBE	低噪 音频	50V0.8A0.625W COM BC337
BC337	NPN	21a	音频激励低噪	50V0.8A0.625W COM BC327
BC338	NPN	21a	通用 激励	50V0.8A0.6
BC546	NPN	21a	通用	80V0.2A0.5W
BC547	NPN	CBE	通用	50V0.2A0.5W300MHZ
BD135	NPN	29	音频 功放	45V1.5A12.5W
BD136	PNP	29	音频 功放	45V1.5A12.5W
BD137	NPN	29	音频 功放	60V1.5A12.5W
BD138	PNP	29	音频 功放	60V1.5A12.5W

BD139	PNP	29	音频 功放	80V1.5A12.5W
BD237	NPN	29	音频 功放	100V2A25W
BD238	PNP	29	音频 功放	100V2A25W
BD243	NPN	28	音频 功放	45V6A65W
BD244	PNP	28	音频 功放	45V6A65W
BD681	NPN	29	达林顿功放	100V4A40W
BD682	NPN	29	达林顿功放	100V4A40W
BF458	NPN	29	视放	250V0.1A10W
BU208A	NPN	12	彩行	1500V5A12.5W
BU208D	NPN	12	彩行	1500V5A12.5W (带阻尼)
BU323	NPN	28	达林顿功放	450V10A125W
BU406	NPN	28	行管	400V7A60W
BU508A	NPN	28	行管	1500V7.5A75W
BU508A	NPN	28	行管	1500V7.5A75W 原
BU508D	NPN	28	行管	1500V7.5A75W (带阻尼)
BU806	NPN	28	功放	400V8A60W DAR-L
BU932R	NPN	12	功放	500V15A150W DAR-L
BU941	NPN	12		
BU1508DX	NPN	28	开关 功放	
BU2506DX	NPN	30	开关 功放	1500V7A50W /600NS
BU2508AF	NPN	30	开关 功放	700V8A125W /600NS
BU2508AX	NPN	30	开关 功放	700V8A125W /600NS
BU2508DF	NPN	30	开关 功放	700V8A125W/600NS(带阻尼)
BU2508DX	NPN	30	开关 功放	1500V8A50W/600NS(带阻尼)
BU2520AF	NPN	30	开关 功放	800V10A150W 1/500NS
BU2520AX	NPN	30	开关 功放	1500V10A150W 1/500NS
BU2520DF	NPN	30	开关 功放	800V10A150W1/500NS(带阻)
BU2520DX	NPN	30	开关 功放	1500V10A50W/600NS (带阻)
BU2522AF	NPN	30	开关 功放	1500V11A150W /350NS
BU2522AX	NPN	30	开关 功放	1500V11A150W /350NS

BU2525AF	NPN	30	开关 功放	1500V12A150W /350NS
BU2525AX	NPN	30	开关 功放	1500V12A150W /350NS
BU2527AF	NPN	30	开关 功放	1500V15A150W
BU2532AW	NPN	30	开关 功放	1500V15A150W(大屏)
BUH515	NPN	BCE	行管	1500V10A80W
BUH515D	NPN	BCE	行管	1500V10A80W(带阻尼)
BUS13A	NPN	12	开关 功放	1000V15A175W
BUS14A	NPN	12	开关 功放	1000V30A250W
BUT11A	NPN	28	开关 功放	1000V5A100W
BUT12A	NPN	28	开关 功放	450V10A125W
BUV26	NPN	28	音频功放开关	90V14A65W /250ns
BUV28A	NPN	28	音频功放开关	225V10A65W /250ns
BUV48A	NPN	30	音频功放开关	450V15A150W
BUW13A	NPN	30	功放开关	1000V15A150W
BUX48	NPN	12	功放开关	850V15A125W
BUX84	NPN	30	功放开关	800V2A40W
BUX98A	NPN	12	功放开关	400V30A210W5MHZ
DTA114	PNP		10K-10K	160V0.6A0.625W(带阻)
DTC143	NPN		录像机用	4.7K-4.7K
HPA100	NPN	BCE	大屏彩显行管	21#
HPA150	NPN	BCE	大屏彩显行管	21#
HSE830	PNP	BCE	音频功放	80V115W1MHZ
HSE838	NPN	BCE	音频功放	80V115W1MHZ COP/MJ4502
MN650	NPN	BCE	行管	1500V6A80W
MJ802	NPN	12	音频功放开关	90V30A200W
MJ2955	PNP	12	音频功放开关	60V15A115W
MJ3055	NPN	12	音频功放开关	60V15A115W
MJ4502	PNP	12	音频功放开关	90V30A200W COP/MJ802
MJ10012	NPN	12	达林顿	400V10A175W
MJ10015	NPN	12	电源开关	400V50A200W

MJ10016	NPN	12	电源开关	500V50A200W
MJ10025		12	电源开关	850V20A250W
MJ11032	NPN	12	电源开关	120V50A300W DAR-L
MJ11033	PNP	12	电源开关	120V50A300W DAR-L
MJ13333	NPN	12	电源开关	400V20A175W
MJ15024	NPN	12	音频功放开关	400V16A250W4MHZ(原25.00)
MJ15025	PNP	12	音频功放开关	400V16A250W4MHZ(原25.00)
MJE271	PNP	29	达林顿	
MJE340	NPN	29	视放	300V0.5A20W
MJE350	PNP	29	视放	300V0.5A20W
MJE2955T	PNP	BCE	音频功放开关	60V1075W2MHZ
MJE3055T	NPN	BCE	音频功放开关	70V1075W2MHZ
MJE5822	PNP	BCE	音频功放开关	500V8A
MJE9730	NPN	BCE		
MJE13003	NPN	29	功放开关	400V1.5A14W
MJE13005	NPN	28	功放开关	400V4A60W
MJE13007	NPN	28	功放开关	1500V2.5A60W
SE800				
TIP31C	NPN	BCE	功放开关	100V3A40W3MHZ
TIP32C	PNP	BCE	功放开关	100V3A40W3MHZ
TIP35C	NPN	30	音频功放开关	100V25A125W3MHZ
TIP36C	PNP	30	音频功放开关	100V25A125W3MHZ
TIP41C	NPN	30	音频功放开关	100V6A65W3MHZ
TIP42C	PNP	30	音频功放开关	100V6A65W3MHZ
TIP102	NPN	28	音频功放开关	100V8A2W
TIP105		28	音频功放开关	
TIP122	NPN	28	音频功放开关	100V8A65W DARL
TIP127	PNP	28	音频功放开关	100V8A65W DARL
TIP137	PNP	28	音频功放开关	100V8A70W DARL
TIP142	NPN	30	音频功放开关	100V10A125W DAR-L

TIP142大	NPN	30	音频功放开关	100V10A125W DAR-L
TIP147	PNP	30	音频功放开关	100V10A125W DAR-L 0
TIP147大	PNP	30	音频功放开关	100V10A125W DAR-L 0
TIP152			电梯用	
TL431		21	电压基准源	
UGN3120		SG0	霍尔开关	
UGN3144		SG0	霍尔开关	
60MIAL1			电磁/微波炉	1000V60A300W
T30G40	NPN	BCE	大功率开关管	400V30A300W
5609				COML:5610
5610				COML:5609
9626				NPN21 通用